

INSTRUCTIONS FOR CHARGER AND BATTERIES

SAVE THESE INSTRUCTIONS

This manual contains important safety and operating instruction for Lincoln Model 1210 Battery Charger.

1. Before using this battery charger, read all instructions and cautionary markings on Battery Charger, Battery Pack, and product using battery.
2. CAUTION: To reduce the risk of injury, the Lincoln Model 1210 Charger should only be used to charge Lincoln battery pack Model 1201. Other types of batteries may burst causing personal injury and damage. Do not charge Lincoln Model 1201 Battery Packs with any other charger.
3. Do not expose charger to moisture (rain, snow or frost).
4. Do not abuse cord. Never carry charger by cord or yank it to disconnect from receptacle. Pull by plug rather than cord when disconnecting charger. Replace damaged or worn power cord and strain reliever immediately. DO NOT ATTEMPT TO REPAIR POWER CORD.
5. Make sure cord is located so that it will not be stepped on, tripped over, or otherwise subjected to damage or stress.
6. Do not use an extension cord unless absolutely necessary. Use of improper extension cord could result in a risk of fire and electric shock. If an extension cord must be used, make sure:
 - A That the extension cord is properly wired and in good electrical condition.
 - B Wire Size of cord is at least as specified in following chart:

LENGTH OF CORD IN FEET (M)	25 (7.5)	50 (15)	100 (30)	150 (45)
AWG SIZE OF CORD (mm ²)	18 (1)	18 (1)	18 (1)	16 (1.5)

- C If an extension cord is to be used outdoors it must be marked with the suffix W-A following the cord type designations. For example -SJTW-A to indicate it is acceptable for outdoor use.
7. Do not operate charger if it has received a sharp blow, been dropped, or otherwise damaged in any way, take it to a qualified serviceman.
8. Do not disassemble charger or battery pack. Take it to a qualified serviceman when service or repair is required. Incorrect reassembly may result in risk of electrical shock or fire.
9. Unplug charger from outlet before attempting any maintenance or cleaning to reduce risk of electric shock.
10. Charge the battery pack in a well ventilated place, do not cover the charger and battery with a cloth, etc., while charging.
11. Do not store the charger or battery packs in locations (such as a metal tool shed, or a car in the summer) where the temperature may reach or exceed 122° F (50° C), which can lead to deterioration of the storage battery.
12. Do not charge battery pack when the temperature is BELOW 32° F (0° C) or ABOVE 104° F (40° C). This is very important for proper operation.
13. Do not incinerate battery pack It can explode in a fire.
14. Do not short across the terminals of the battery pack. EXTREMELY HIGH TEMPERATURES COULD CAUSE PERSONAL INJURY OR FIRE.
15. Charging time will be approximate 1 hour after the initial charge.

* New batteries are shipped in an uncharged state and the initial charge will require 12 hours before use.

16. When green light comes on indicating charge is complete, remove battery from charger. **Do not leave battery plugged into charger for an extended period of time after charge is complete.**
17. Dispose of expended batteries properly. The Lincoln Model 1201 Battery Pack contains rechargeable, nickel-cadmium batteries. These batteries must be recycled or disposed of properly. Drop off expended battery packs at your local replacement battery retailer, or your recycling center.

Users in the United States NOTE:
Applicable fees for the collection and recycling of these batteries have been paid to the RBRCTM. For further information, call 1-800-8BATTERY.

Product Specifications

Input Voltage	120 VAC/60 Hz @ 375MA
Output	14.5 Volts @ 1.5 Amps
Time to Charge	
1201 Battery:	1 Hour Approx.
Cord Length	6 ft (2 m)
Weight	1 lb. (0.45 Kg)

Indicator Lights

Red and Green Light On

When plugging in charger both the red & green light will come on for 2 seconds.

Green Light Flashes

1. Ready to charge but no battery in charger
2. Charger does not recognize the battery because it is too hot to charge. Once battery cools to an acceptable level charge will begin

Red Light On - Battery is being charged

Green Light On - Battery is fully charged

Red and Green Lights Alternate Flashing

When battery voltage is below 9 VDC the battery will be evaluated. This can last up to 5 minutes.

Red Light Flashes

Replace Battery pack. Unplug the charger if the red light continues to flash after the defective battery is removed. Replace the defective battery do not attempt to charge it again.



© Indicates change

Americas: One Lincoln Way St. Louis, MO 63120-1578 USA Phone +1.314.679.4200 Fax +1.800.424.5359	Europe/Africa: Heinrich-Hertz-Str 2-8 D-69183 Walldorf Germany Phone +49.6227.33.0 Fax +49.6227.33.259	Asia/Pacific: No. 3 Tampines Central 1 #04-05, Abacus Plaza. Singapore 529540 Tel +65.6588.0188 Fax +65.6588.3438	© Copyright 2010 Printed in USA Web site: www.lincolnindustrial.com
---	---	--	--

**Model 1210
PowerLuber Battery Charger
Series "C"**



Lincoln Industrial Standard Warranty

LIMITED WARRANTY

Lincoln warrants the equipment manufactured and supplied by Lincoln to be free from defects in material and workmanship for a period of one (1) year following the date of purchase, excluding therefrom any special, extended, or limited warranty published by Lincoln. If equipment is determined to be defective during this warranty period, it will be repaired or replaced, within Lincoln's sole discretion, without charge.

This warranty is conditioned upon the determination of a Lincoln authorized representative that the equipment is defective. To obtain repair or replacement, you must ship the equipment, transportation charges prepaid, with proof of purchase to a Lincoln Authorized Warranty and Service Center within the warranty period.

This warranty is extended to the original retail purchaser only. This warranty does not apply to equipment damaged from accident, overload, abuse, misuse, negligence, faulty installation or abrasive or corrosive material, equipment that has been altered, or equipment repaired by anyone not authorized by Lincoln. This warranty applies only to equipment installed, operated and maintained in strict accordance with the written specifications and recommendations provided by Lincoln or its authorized field personnel.

THIS WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

In no event shall Lincoln be liable for incidental or consequential damages. Lincoln's liability for any claim for loss or damages arising out of the sale, resale or use of any Lincoln equipment shall in no event exceed the purchase price. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, therefore the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights. You may also have other rights that vary by jurisdiction.

Customers not located in the Western Hemisphere or East Asia: Please contact Lincoln GmbH & Co. KG, Walldorf, Germany, for your warranty rights.

Lincoln Industrial Special Limited Warranties

SPECIAL LIMITED 2 YEAR WARRANTY-

SL-V Series, Single Injectors-85772, 85782, and Replacement Injectors-85771, 85781

Lincoln warrants the SL-V Injector series to be free from defects in material and workmanship for two (2) years following the date of purchase. If an injector model (single or replacement) is determined to be defective by Lincoln, in its sole discretion, during this warranty period, it will be repaired or replaced, at Lincoln's discretion, without charge.

SPECIAL LIMITED 5 YEAR WARRANTY-

Series 20, 25, 40 Bare Pumps, PMV Bare Pumps, Heavy Duty and 94000 Series Bare Reels

Lincoln warrants series 20, 25, 40 bare pumps, PMV bare pumps, Heavy Duty (82206), Mini Bench (81133, 81323), and 94000 LFR series (94100, 94300, 94500) bare reels to be free from defects in material and workmanship for five (5) years following the date of purchase. If equipment is determined by Lincoln, in its sole discretion, to be defective during the first year of the warranty period, it will be repaired or replaced at Lincoln's discretion, without charge. In years two (2) and three (3), the warranty on this equipment is limited to repair with Lincoln paying parts and labor only. In years four (4) and five (5), the warranty on this equipment is limited to repair with Lincoln paying for parts only.

SPECIAL LIMITED 5 YEAR WARRANTY-

LFM Series Oil Meters (Lincoln Fluid Meter), LFV (Lincoln Fluid Valves), AOD (Air-Operated Diaphragm Pumps)-

Lincoln warrants the LFM meter series (908/912 series), the Lincoln Fluid valve (708/712 series), our Universal Inline Digital Meters (812/813 series), and our AOD Pump offering to be free from defects in material and workmanship for five (5) years following the date of purchase. If either is determined to be defective by Lincoln, in its sole discretion, during the warranty period, they will be repaired or replaced, at Lincoln's discretion, without charge.

Lincoln Industrial Contact Information

To find Lincoln Industrial's Nearest Service Center call the following number, you may also use our website

Customer Service 314-679-4200
Website lincolnindustrial.com