



Service Couplings

C3B12 / ON2

Crankcase Receiver and Cap




To order receiver with cap, specify ONC2A



A1804 / P1880

Transmission Receiver and Cap




OS2

Crankcase Nozzle and Plug



To order nozzle with plug (OP12), specify OSP2

Mates with ON2 and ONC2A Receivers



C1807 / P1844

Transmission Nozzle and Plug

