



## Service Couplings

### C3B12 / ON2

Crankcase Receiver and Cap




To order receiver with cap, specify ONC2A



### A1804 / P1880

Transmission Receiver and Cap




### OS2

Crankcase Nozzle and Plug



To order nozzle with plug (OP12), specify OSP2

Mates with ON2 and ONC2A Receivers



### C1807 / P1844

Transmission Nozzle and Plug

